

Product Manual: How to Install Aluminium Floor Bunding

Installation is straightforward. The process requires minimal experience.

- 1.** Ensure the surface under the floor bunding is appropriate
- 2.** Clean the surface so it's free of anything that could affect adhesion
- 3.** Layout your bunding to determine you have enough materials
- 4.** Cut lengths as required to custom fit your layout
- 5.** Layout the bunding using a chalk line and leave a 2-3mm gap in between lengths (for expansion)
- 6.** Pre-drill holes for the concrete fasteners
- 7.** Vacuum away the dust
- 8.** Apply adhesive to the bottom of the floor bunding and adhere to ground surface.
- 9.** Insert the concrete screws
- 10.** Once the lengths are installed, run a bead of adhesive along both sides where it meets the ground and in the gap between the lengths
- 11.** Allow the adhesive to cure before using the bunding

