

Installation is simple.

Minimum tools are required and the drive over floor bunding can be cut easily.

Each length and corner of drive overfloor is manufactured with pre-moulded points for bolts to assist with installation.

The required banded areas can be easily configured using the moulded 90° corner pieces.

Each 1m length installation kit consists of:

- 6 x countersunk concrete fasteners
- 1 x tube of adhesive sealant

Before purchasing floor bunding ensure you check ground clearance of forklifts.

