

PREPARATION

The ground surface where the floor bund will be installed must be clean and free of dust, debris, oil, grease and any other contaminate that may affect the adhesion. If the ground surface is very dusty or in poor condition, it would be best to paint or seal it first in order to obtain a perfect seal between the surface and floor bunding.

INSTALLING FLEXIBLE FLOOR BUNDING

- Mark out the area to be installed with a chalk line.
- Place the Flexible Floor Bunding (FFB) sections in the required configurations and cut to the correct dimensions. Where a join is required, cut away enough foam to allow PVC to overlap.
- Lay the FFB in place where it will be installed.
- Liberally apply adhesive to the underside of the FFB and lay in place along the chalk line.



- Drill through the rubber and bunding into the concrete underneath
- Vacuum away the resulting dust.
- Insert the concrete masonry fasteners – the first one at 25mm in from the end and another every 300mm down the length of the FFB.
- Where using corner pieces, over lap the straight sections of the Flexible Floor Bund and glue with PVC glue.
- Allow the adhesive to cure before walking on or driving over the floor bunding.

BILL OF MATERIALS

Each 10m of Flexible Floor Bund sections will require the following for installation

- Adhesive sealant x 2 tubes
- Rubber strip x 2 rolls (10mL x 50mmW)
- Fasteners x 70 (5mm x 38mm nylon anchor round head screw)

